AUTEL TPMS TOOLS COMPARISON

Features & Functions	MX-PAD	TS508	TS608	MS906TS	
Quick Mode & Advance Mode		•			
Activate TPMS Sensors	•	•	•	•	
Read Sensor Data	•	•	•	•	S
TPMS Diagnose, One Step For Complete TPMS		•	•	•	Ž
Read / Clear TPMS DTCs; On-Screen DTC Description		•	•		\succeq
Scan TPMS Sensor ID and Copy ID to MX-Sensor	•	•	•	•	<u>ပ</u>
Manual Input OE ID into MX-Sensor	•	•	•		5
Program MX-Sensor By Auto Create Sensor ID	•	•	•		II.
Read Sensor ID by OBD and Copy ID into MX-Sensor		•	•	•	SIN
Relearn by OBD Function		•	•	•	TPMS FUNCTIONS
Relearn Procedure Guide On The Tool		•	•	•	
Check Key FOB		•	•		
TPMS Toolkit - Unique TPMS Functions			•		
Basic OBD Code Reader			•	•	
Read / Clear Codes For All Electronic Systems			•	•	NS
Support All 10 Test Modes - Latest J1979 Specs			•	•	<u>0</u>
Enhanced OBDII Mode 6			•	•	FUNCTION
Display Live Data Text / Graph / Analog For Easy Review			•	•	Ž
Relearn Parking Brake Pad After Replacement (EPB)			•	•	
Reset Steering Angle Sensor (SAS)			•	•	· 임
Reset Oil Light (Oil Reset)			•	•	S
Forced DPF Regeneration & Adjusting Injectors (DPF)			•	•	AGNOSTIC
Support Battery Registration & Reset (EMS)			•	•	4 G
Support IMMO Functions			•	•	<u>/</u>
Complete Diagnostic Function				•	
Software Updates & Current Vehicle Coverage	FREE	FREE	1 Year Free	1 Year Free	(0
Limited One Year Warranty	•	•	•	•	TOOL FEATURES
Print TPMS Sensor Data Via PC	•	•	•	•	H
Internet Updateable	USB	USB	WiFi	WiFi	A
Multi-Lingual Support	•	•	•	•	H
Historical Test Records				•	
Built-In Rechargeable Li-Ion Battery		2400mAH	5000mAH	10,000mAH	0
Strong Housing With Protective Rubber Boot					