




Please Note: The following instructions are compatible with any computer with a functional Internet connect. Please ensure your Internet is working properly before you proceed.




- Visit <http://pro.autel.com>
- Click **Create Autel ID** on left side of screen
- If you already have an Autel ID, sign in, then skip to Step 6




- Set preferred language
- Enter email address as Autel ID
- Click **Get Verification Code**




- An email titled "Verification Code for New User Registration" will be sent to you.
- Open email and copy 6-digit verification code in red
- Go back to <http://pro.autel.com> to continue registration




- Enter verification code and all other required information marked with a red asterisk (verification code screen shown on Step 2)
- Type in Captcha code as shown
- Ensure Autel Terms of Use and Privacy Policy box is checked




- Click **Create Autel ID** at bottom of screen (screen shown on Step 4)
- Registration Complete screen will display.
- Click **Sign in Now** and log in



- Product Registration screen will display.
- Select **TS508** from Product Model drop-down menu




- On TS508 tool, use UP/DOWN and LEFT/RIGHT buttons to select **My Device**
- On tool press **Y** button, select **About**, then press **Y** button again
- Product information screen will display on tool.




- On PC input Product Serial Number and Password as displayed on tool
- Type in Captcha code as shown
- Click Submit to complete registration


Please Note: The following instructions are compatible with any computer with a functional Internet connect. Please ensure your Internet is working properly before you proceed.




- On tool select **My Device**
- Press **Y** button
- Select **Update**
- Press **Y** button



- Connect TS508 to Windows computer via USB cable
- Press and hold Left arrow button to update




- A chart with a listing for PC software will display.
- Select **Autel PC Suite**
- Click **Download**




- Once downloaded, double-click **Setup.exe**
- The Autel Update and Autel Printer shortcuts will display on PC.
- Double-click on **Autel Update** shortcut
- Enter Autel ID and Password (shown on Step 5)




- If you forget your password, click **Forget Password** and follow instructions
- Click the **Updates** tab
- A list of software updates will display.



- **DO NOT SELECT ALL. SELECT ONE UPDATE AT A TIME**
- Ensure C Drive is selected
- Click **Install** button in line of program to update



- If needed, click **Pause** button
- Click **Install** button to resume download



- Downloaded programs are installed automatically and will replace older version.
- Disconnect tool from computer when update is complete