

Table of Contents

1.	SAFETY PRECAUTIONS AND WARNINGS.....	1
2.	GENERAL INFORMATION.....	2
2.1	TPMS SYSTEM REVIEW	2
2.2	TPMS LEGISLATION	2
2.3	TPMS TELL-TALE LIGHT	2
2.4	BENEFITS OF TPMS	3
3.	TOOL INFORMATION.....	4
3.1	TOOL DESCRIPTION	4
3.2	SPECIFICATIONS.....	6
3.3	ACCESSORIES INCLUDED.....	6
3.4	ICONS	7
3.5	KEYBOARD	7
3.6	BATTERY CHARGING	7
3.7	POWER UP BY DLC.....	8
3.8	SYSTEM SETTING	9
3.9	PRODUCT TROUBLESHOOTING.....	16
4.	TPMS CHECK & DIAGNOSTICS	18
4.1	TPMS SENSOR CHECK	18
4.2	TPMS RELEARN	28
4.3	AUDIT REPORT.....	41
5.	RKE & RF MONITOR.....	43
6.	OBDII DIAGNOSTICS	45
6.1	READ CODES	46
6.2	ERASE CODES.....	48

6.3	LIVE DATA	49
6.4	FREEZE FRAME	51
6.5	RETRIEVING I/M READINESS STATUS	52
6.6	O2 MONITOR TEST	54
6.7	ON-BOARD MONITOR TEST	55
6.8	COMPONENT TEST	57
6.9	VIEWING VEHICLE INFORMATION	58
6.10	MODULES PRESENT	59
7.	REVIEW DATA	60
8.	PRINT AND UPDATE.....	62
8.1	PRINT DATA	62
8.2	SOFTWARE UPDATE	63
9.	COMPLIANCE INFORMATION.....	69
10.	WARRANTY AND SERVICE.....	70
10.1	LIMITED ONE YEAR WARRANTY	70
10.2	SERVICE	70

1. Safety Precautions and Warnings

To prevent personal injury or damage to vehicles and/or the scan tool, read this instruction manual first and observe the following safety precautions at a minimum whenever working on a vehicle:

- Always perform diagnosis or service in a safe environment.
- Wear safety eye protection that meets ANSI standards.
- Keep clothing, hair, hands, tools, test equipment, etc. away from all moving or hot engine parts.
- Operate the vehicle in a well ventilated work area: Exhaust gases are poisonous.
- Put blocks in front of the drive wheels and never leave the vehicle unattended while running tests.
- Use extreme caution when working around the ignition coil, distributor cap, ignition wires and spark plugs. These components create hazardous voltages when the engine is running.
- Keep a fire extinguisher suitable for gasoline/chemical/electrical fires nearby.
- Put the transmission in PARK (for automatic transmission) or NEUTRAL (for manual transmission) and make sure the parking brake is engaged.
- Always turn the ignition off before connecting/disconnecting the OBDII Cable to/from the TPMS tool; otherwise it may cause the Malfunction Indicator Light (MIL) to turn on.
- Refer to the user's manual for the vehicle being serviced and adhere to all diagnostic procedures and precautions. Otherwise personal injury or unneeded repairs may result.
- Keep the TPMS tool dry, clean, free from oil, water and grease. Use a mild detergent on a clean cloth to clean the outside of the TPMS tool when necessary.

2. General Information

2.1 TPMS system review

A tire pressure monitoring system (TPMS) is an electronic system designed to monitor the air pressure inside the pneumatic tires on various types of vehicles. TPMS report real-time tire-pressure information to the driver of the vehicle, either via a gauge, a pictogram display, or a simple low-pressure warning light. TPMS can be divided into two different types — direct (dTPMS) and indirect (iTPMS). TPMS are provided both at an OEM (factory) level as well as an aftermarket solution.

2.2 TPMS Legislation

In the United States, the United States Department of Transportation (NHTSA) released the FMVSS No. 138, which requires an installation of a Tire Pressure Monitoring System to all new passenger cars, multipurpose passenger vehicles, trucks, and buses that have a gross vehicle weight rating (GVWR) of 4,536 kg (10,000 lbs.) or less, except those vehicles with dual wheels on an axle, as of 2007. In the European Union, starting November 1, 2012, all new models of passenger cars must be equipped with a TPMS, with even tighter specifications that will be defined by the UNECE Vehicle Regulations (Regulation No. 64). From November 1, 2014, all new passenger cars sold in the European Union must be equipped with TPMS. On July 13, 2010, the South Korean Ministry of Land, Transport and Maritime Affairs announced a pending partial-revision to the Korea Motor Vehicle Safety Standards (KMOVSS), specifying that "TPMS shall be installed to passenger vehicles and vehicles of GVW 3.5 tons or less, ... [effective] on January 1, 2013 for new models and on June 30, 2014 for existing models". Japan is expected to adopt European Union legislation approximately one year after European Union implementation. Further countries to make TPMS mandatory include Russia, Indonesia, the Philippines, Israel, Malaysia and Turkey.

2.3 TPMS tell-tale light

When diagnosing TPMS systems, you should understand what the TPMS tell-tale light means.

When turning the ignition OFF to ON, the TPMS tell-tale should come on, and then go off, which indicates the system is working fine. If the light stays on, there would be a pressure problem. If the light flashes, there would be a system problem, which can range from faulty sensors to sensors on the vehicle that haven't been learned to that vehicle.

2.4 Benefits of TPMS




The significant advantages of TPMS are summarized as follows:

- Fuel saving.
- Extended tire life.
- Decreased downtime and maintenance.
- Improved safety.
- Environmental efficiency.









3. Tool Information

3.1 Tool Description



- 1)  **SIGNAL MARK** – Indicates where the tool sends or receives signals.
- 2) **LCD DISPLAY** – Displays the menus and test screens.
- 3)  **FUNCTION BUTTONS** – Corresponds with “buttons” on screen for executing commands.
- 4)  **UP SCROLL BUTTON** – Moves up through menu and submenu items in menu mode. When more than one set of data are retrieved, use this button to move up to previous screens for

additional data. It is also used to view previous trouble code when viewing DTCs.

- 5)  **N BUTTON** – Cancels a selection (or action) from a menu or return to previous menu.
- 6)  **LEFT SCROLL BUTTON** –When scrolling through a screen of data or text, moves to previous character and views additional information on previous screens if recorded data content covers more than one screen.
- 7)  **HELP BUTTON** – Provides help information.
- 8)  **POWER BUTTON** – Press and hold this button to turn on/off the tool; or, press the button shortly to return to Home screen.
- 9)  **DOWN SCROLL BUTTON** – Moves down through menu and submenu items in menu mode. When more than one set of data are retrieved, use this button to move down to next screens for additional data. It is also used to view next trouble code when viewing DTCs.
- 10)  **RIGHT SCROLL BUTTON** – When scrolling through a screen of data or text, moves to next character and view additional information on next screens if recorded data content covers more than one screen.
- 11)  **Y BUTTON** – Confirms a selection (or action) from a menu.
- 12)  **FUNCTION BUTTON/TEST BUTTON** – Corresponds with “buttons” onscreen for executing commands, or commences a TPMS Test in sensor activation mode.
- 13) **USB PORT** – Connects the TPMS tool to PC for software update, data printing or battery charging.

- 14) **POWER PORT** – Connects the TPMS tool to the mains with the charger supplied for battery charging.
- 15) **SD CARD SLOT** – Holds SD card.
- 16) **OBD II CONNECTOR** – Connects the TPMS tool to the vehicle's Data Link Connector (DLC).

3.2 Specifications

- 1) Display: TFT color display (320 x 240 dpi)
- 2) Power: 3.7V Li-polymer battery
- 3) Operating Temperature: 0 to 50 °C (32 to 122 °F)
- 4) Storage Temperature: -20 to 70 °C (-4 to 158 °F)
- 5) Dimensions:

Length	Width	Height
202.2 mm (7.96")	106.7mm (4.20")	37.7 mm (1.48")










- 6) Weight: 0.4kg (0.88lb)

3.3 Accessories Included

- 1) **User's Manual** -- Instructions on tool operations.
- 2) **OBDII Cable** -- Provides power to tool and communicates between tool and vehicle.
- 3) **USB Cable** -- Allows easy online update, data printing, and power charging via PC connection.
- 4) **Carry Case** -- A case to store the tool when not in use.
- 5) **Magnet** -- Used to trigger magnetically activated sensors (early model TPMS sensors).
- 6) **Power Adapter** -- Charges the built-in battery.

- 7) **CD** -- Includes user's manual, PC Suit, etc.
- 8) **SD Card** -- Used to store data.

3.4 Icons

- 1) “” -- Indicates battery charging.
- 2) “” -- Indicates there is data stored in the tool.
- 3) “” -- Indicates battery volume.
- 4) “” -- Indicates USB communication with the computer is established.
- 5) “” -- Indicates magnet is required to activate TPMS sensor.
- 6) “P ↓” -- Indicates deflation is required to activate TPMS sensor.
- 7) “” -- Indicates test mode **One Wheel** is selected.
- 8) “” -- Indicates test mode **ALL Wheels** is selected.
- 9) “” -- Indicates the TPMS tool is sending signals to the tire sensor for activation and test.
- 10) “” -- Indicates tool communication with the vehicle's OBDII DLC is established.

3.5 Keyboard


No solvents such as alcohol are allowed to clean the keypad or display. Use a mild nonabrasive detergent and a soft cotton cloth. Do not soak the keypad as the keypad is not waterproof.

3.6 Battery Charging

The TPMS tool has a 3.7V built-in lithium-ion polymer rechargeable battery. There are two means of battery charging:

- ✓ To charge battery by power adapter.
 - 1) Locate the power port of the device.
 - 2) Connect the device and the power source with the adapter.
- ✓ To charge battery by USB cable
 - 1) Locate the USB port of the device.
 - 2) Connect the device and the computer with the USB cable.

For optimum performance, always keep your tool sufficiently charged. It is recommended that you charge the tool for over 2 hours before the first use.

 ***NOTE: Only use the power adaptor or USB cable that is included in our pack to charge this tool. The use of un-approved power supplies may damage your tool and void the tool warranty.***

3.7 Power Up by DLC

The tool can also be powered via the vehicle Data Link Connector (DLC). Just follow the steps below to turn on the TPMS tool:

- 1) Connect the OBDII Cable to the TPMS tool.
 - 2) Find DLC on vehicle.
- ***A plastic DLC cover may be found for some vehicles and you need to remove it before plugging the OBDII cable.***
- 3) Plug OBDII cable to the vehicle's DLC.
 - 4) Power up the TPMS tool by pressing the **Power Button**, and wait for the Main Menu to appear. (Figure 3.1)



Figure 3.1

3.8 System Setting

The tool allows you to make the following adjustments and settings.

- 1) **Language:** Selects the desired language.
 - 2) **Beep Set:** Turns on/off key-press beep.
 - 3) **ID Format:** Sets the ID displaying in Hexadecimal or Decimal.
 - 4) **Pressure Unit:** Sets the pressure unit in Kpa, Psi or Bar.
 - 5) **Temperature Unit:** Sets the temperature unit in degree Celsius or Fahrenheit.
 - 6) **Wheels to Test:** Gives the operator the choice to test One wheel or All wheels.
 - 7) **Distance Unit:** Sets the distance unit in Km or mile.
 - 8) **Auto Power-off:** Sets the time to power off automatically.
 - 9) **About:** Views important information of the tool.
- *Settings of the unit will remain until change to the existing settings is made.*

To enter the Setting menu

From the **Main Menu**: Use the **UP/DOWN** and **LEFT/RIGHT** scroll button to select **Setting**, and press the **Y** button. Following the

instructions to do adjustments and settings could make TPMS testing more convenient and easy. (Figure 3.2)



Figure 3.2


Language

- **English is the default language.**

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **Language**, and press the **Y** button.
- 2) Use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select the desired language and press the **Y** button to save your selection and return to previous menu. (Figure 3.3)



Figure 3.3

 **NOTE:** The current version of TS601 TPMS tool supports only the English language, and there will be more languages coming with new updates released.

Beep Set

This function allows you to turn on/off the built-in speaker for key pressing.

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **Beep Set**, and press the **Y** button.
- 2) From **Beep Set** menu, use the **LEFT/RIGHT** scroll button to select **ON** or **OFF** to turn on/off the beep.(Figure 3.4)




Figure 3.4

- 3) Press the **Y** button to save your selection or the **N** button to exit without change.

ID Format

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **ID Format**, and press the **Y** button.
- 2) From **ID Format** screen, use the **LEFT/RIGHT** scroll button to select the desired format of ID. (Figure 3.5)




Figure 3.5

- 3) Press the **Y** button to save your settings and return to previous menu, or press the **N** button to exit without change.

Pressure Unit

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **Pressure Unit**, and press the **Y** button.
- 2) From **Pressure Unit** screen, use the **LEFT/RIGHT** scroll button to select the desired unit: **Kpa**, **Psi** or **Bar**. (Figure 3.6)



Figure 3.6

- 3) Press the **Y** button to save your settings and return to previous menu, or press the **N** button to exit without change.

Temperature Unit

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **Temperature Unit**, and press the **Y** button.
- 2) From **Temperature Unit** screen, use the **LEFT/RIGHT** scroll button to select the desired unit of temperature.(Figure 3.7)




Figure 3.7

- 3) Press the **Y** button to save your settings and return to previous menu, or press the **N** button to exit without change.

Wheels to Test

This function gives you choice to test TPMS sensor in All Wheels mode or One Wheel mode.

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **Wheels to Test**, and press the **Y** button.
- 2) From **Wheel to test** screen, use the **LEFT/RIGHT** scroll button to select **All Wheels** or **One Wheel** mode for TPMS sensor testing. (Figure 3.8)




Figure 3.8

- 3) Press the **Y** button to save your selection or the **N** button to exit without change.

NOTE: In *All Wheels* mode, the tool will determine if a duplicate sensor ID has been read. In this case, the tool will display a message “*Sensor ID Duplicated.*” In *One Wheel* mode, the tool will not check the duplicate sensor ID.

Distance Unit

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **Distance Unit**, and press the **Y** button.
- 2) From **Distance Unit** screen, use the **LEFT/RIGHT** scroll button to select the desired unit of distance: **Km** or **mile**. (Figure 3.9)




Figure 3.9

- 3) Press the **Y** button to save your settings and return to previous menu, or press the **N** button to exit without change.

Power-off

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **Power-off**, and press the **Y** button.
- 2) Press the **UP/DOWN SCROLL** button to increase or decrease the time to auto power-off the tool, and then press the **Y** button to confirm your change or the **N** button to exit without change. (Figure 3.10)




Figure 3.10

- ❏ **NOTE:** Before the tool powers off automatically, it will save all the TPMS test data. Next time when the tool is powered on, you may retrieve the recorded data. If the tool automatically powers off during a test operation, next time when the tool is powered on, it will automatically turn to the previous operation screen.
- ❏ **NOTE:** When using external power, the scan tool stays on until you turn it off. When using internal battery power, the scan tool turns off automatically after a set time of inactivity.

About

This function allows viewing of some important information such as serial number and software version number of the tool.

- 1) From System **Setting** screen, use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **About**, and press the **Y** button; wait for the **About** screen to appear.
- 2) View tool information on screen. (Figure 3.11) Press the **N** button to exit.



Figure 3.11

3.9 Product Troubleshooting

This part describes problems that you may encounter while using the TPMS tool.

Vehicle Linking Error

A communication error occurs if the TPMS tool fails to communicate with the vehicle's ECU (Electronic Control Unit) when running the diagnostic function. You need to do the following to check up:

- ✓ Verify that the ignition is ON.
- ✓ Check if the TPMS tool's OBD II connector is securely connected to the vehicle's DLC.
- ✓ Verify that the vehicle is OBD II compliant.
- ✓ Verify that the vehicle is equipped with TPMS.
- ✓ Verify the tool battery is sufficiently charged.
- ✓ Turn the ignition off and wait for about 10 seconds. Turn the ignition back to on and continue the testing.

- ✓ Verify the control module is not defective.

Operating Error

If the scan tool freezes, then an exception occurs or the vehicle's ECU (Engine Control Unit) is too slow to respond to requests, do the following to reset the tool:

- ✓ Reset the scan tool.
- ✓ Turn the ignition off and wait for about 10 seconds. Turn the ignition back to on and continue the testing.

4. TPMS Check & Diagnostics

The MaxiTPMS® TS601 is a new generation TPMS diagnostic & service tool specially designed to activate all known OEM/Universal TPMS sensors, and provide users with direct access to the vehicle's ECU through OBDII connection, thus allowing users to reprogram sensor IDs, retrieve/clear TPMS DTCs, read live data and perform special functions, helping technicians to quickly find out faulty TPMS and turn off MILs.

- ***NOTE: All software screens shown in this manual are examples, actual test screens may vary for each vehicle being tested. Observe the menu titles and onscreen instructions to make correct option selections.***

4.1 TPMS Sensor Check

The sensor check function allows user to activate TPMS sensor to view sensor data such as sensor ID, tire pressure, tire temperature, battery condition, sensor position and OE part number.

There are two means to check a TPMS sensor:

A. Select by Vehicle

Users can start activating sensors directly by selecting the specific vehicle make, model and year. The graphed vehicle with 4 or 5 wheels makes the sensor activation process more simple and convenient.

- 1) Use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **TPMS** from **Main Menu** (Figure 3.1), and press the **Y** button to confirm.
- 2) Select a specific vehicle manufacture's regional coverage. (Taking **Nissan** as an example.)




Figure 4.1

- 3) From the vehicle make screen, select a specific vehicle manufacture and press the **Y** button. (Figure 4.2)



Figure 4.2

- 4) Observe the menu title and use the **UP/DOWN** scroll button to select by model and year to identify the vehicle being tested.
- *The selected vehicle is remembered by the tool when a test is commenced.*

Select by Model:



Nissan	
1	350XV
2	350Z
3	370Z
4	Altima
5	Armada
6	Armada-LE
7	Cube

Figure 4.3


Select by Year:



Nissan 370Z	
1	2009-2010
2	2010 05-2012

Figure 4.4

- 5) For some vehicles an option screen will show up to let users choose between 4 Wheels test and 5 Wheels test mode.



Chrysler Crossfire 2004	
1	4 Wheels
2	5 Wheels

Figure 4.5

- Depending upon the test mode (**All Wheels** or **One Wheel**), results are displayed in different manners.

All Wheels Mode

In this mode, the screen will display as below (Figure 4.6). Use the **UP/DOWN** and **LEFT/RIGHT** scroll button to select a desired wheel and press the **TEST** button to activate sensor.(Figure 4.7)




Figure 4.6



Figure 4.7

- The **TPMS Relearn** function icon on the upper right corner of screen is not supported by all vehicles, but the sensor activating process remains the same. For those vehicles not supported Relearn function, the activation screen displays as Figure 4.8. Detailed information about TPMS Relearn, please refer to **4.2 TMPS Relearn**.



Figure 4.8

The tool will do TPMS test in a sequence of FL (Front Left), FR (Front Right), RR (Rear Right), LR (Rear Left) and SPARE, if the vehicle has the option for the spare. Or, you can use the **UP/DOWN** or **LEFT/RIGHT** scroll button to move to the desired wheel for testing.

Place the tool alongside the valve stem, point toward the sensor location, and press the **TEST** button.

The tool will send LF signal to trigger the sensor. Depending on the sensor type, the tool will activate the sensor on the first or last step. Once the sensor is successfully activated and decoded, the tool will display as below with a beep. (Figure 4.9)




Figure 4.9

- ✓ Wheel with a feedback icon, “✓”, “x”, “D”, indicates wheel test has been finished.
- ✓ Press **Y** button to read all sensor data, including sensor ID, tire pressure, temperature, battery condition and modulation.

One Wheel Mode

In this mode the screen will show as below (Figure 4.10). The tool will check TPMS sensor on the single wheel. Place the tool alongside the valve stem, point toward the sensor location, and press the **TEST** button. Wait for test result before moving the tool.

The tool will send LF signal to trigger the sensor. Depending on the sensor type, the tool will activate the sensor on the first or last step.

Once the sensor is successfully activated and decoded, the tool will display as below with a beep. (Figure 4.11)



Figure 4.10



Figure 4.11

Once the first sensor test is completed, the screen will hold for 3 seconds for data viewing and then switch to next sensor test. Follow the same procedure for the other sensor tests.

The tool can save up to 5 TPMS sensor data records at each time. Press the **UP/DOWN** or **LEFT/RIGHT** scroll button to turn over data screens while viewing. If more than five records are stored, the latest record will overwrite the first one.

TABLE 1 POSSIBLE RESULTS FOR TESTING

Icon	Test Results	Description
✓	Successful Sensor Read	TPMS sensor is successfully activated and decoded. The tool displays the sensor information.
X	Failed Sensor Read	<p>If the search period expires and no sensor is activated or decoded, it may be wrong sensor fitting or non-functioning sensor. The tool displays a message "No sensor detected."</p> <p>In this case, repeat testing to confirm the TPMS failure.</p>
X	Wrong Sensor Type	<p>A TPMS sensor is activated and decoded, but does not match the protocol for the Make, Model or Year that the tool was set-up for. The tool displays a message "Sensor triggered but cannot be known."</p> <p>In this case, verify the Make, Model or Year you have selected as well as the sensor part number that was fitted.</p>
D	Duplicate ID (only checked in All Wheels mode)	<p>A sensor with a duplicate ID has been read. The tool displays a message "Sensor ID Duplicated."</p> <p>In this case, clear data and re-read again.</p>

NOTE: With Ford sensors, the tool should be held 180 degree away from the stem. Please refer to vehicle user's manual.

- If the TPMS sensor requires a magnet, place the magnet over the stem and then place the tool alongside the stem, and press the **TEST** button.




Figure 4.12

- If the TPMS sensor requires tire deflation (of the order of 10PSI), then deflate the tire and place the tool alongside the stem while pressing the **TEST** button.




Figure 4.13

- Anytime while doing the TPMS test, press **? BUTTON** to read the sensor make, OEM part no., and relearn information for the vehicle being tested. Use the **UP/DOWN** scroll button to view all details if the data information covers more than one page.




Figure 4.14

- Sensor activation can be aborted at any time by pressing the **N** button. When the activation is aborted, the user will be returned to the previous menu.
- By pressing the **Y** button, you may review information of all sensors tested. Press the **LEFT/RIGHT** scroll button to turn over data screens while viewing.

Pos	ID-H	Kpa	°C
FL	8000E0	240	38
FR	002020	240	38
RR	00E000	240	38
RL	1E00E0	240	38

[◀▶]=Change Page [N]=Exit 1/2

Figure 4.15

Pos	BAT	Mode	Modulation
FL	OK	TEST	433AM
FR	OK	TEST	433AM
RR	OK	TEST	433AM
RL	OK	TEST	433AM

[◀▶]=Change Page [N]=Exit 2/2

Figure 4.16

[Pos] – Indicates the wheel sensor position.

[ID-H/D] – Shows sensor ID data.

[KPa/Psi/Bar] – Indicates tire pressure.

[°C/°F] – Indicates tire temperature.

[BAT] – Indicates battery condition.

[Mode] – Defines tire sensor working mode or status.

[Modulation] – Indicates sensor signal amplitude.

B. Select by latest test

This function allows you to review the last tested sensor data and activate the sensor by using the wave signal of the latest trigger event, which is very convenient and useful for technicians to wake up sensors of the same vehicle.

- 1) Use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **Latest Test** from **Main Menu** (Figure 3.1).
- 2) An activation screen with the previously activated sensor information will show up (Figure 4.17). Use the **UP/DOWN** or **LEFT/RIGHT** scroll button to select the desired wheel, and press the **TEST** button to reactivate the sensor, or press the **Y** button to view all detailed sensor data (Figure 4.18).




Figure 4.17

Pos	ID-H	Kpa	°C
FL	8000E0	240	38
FR	002020	240	38
RR	00E000	240	38
RL	1E00E0	240	38
[◀▶]=Change Page [N]=Exit 1/2			

Figure 4.18

- 3) If user is going to retest the sensor, a prompt will come up asking for your confirmation.




Figure 4.19

- 4) Select '**Yes**' to delete all test records and enter test mode. Or select "**No**" to reserve the previous data and check the remaining untested sensors.

4.2 TPMS Relearn

This function, which provides users with quick access to the vehicle's ECU, enables users to do TPMS diagnostics, such as reading/writing sensor IDs from vehicle ECU, reading/ clearing codes of TMPS system, reading TPMS live data, retrieving TPMS ECU information, and performing actuation tests and special functions, and to save data for later reviews and printing.

- 1) Connect the TPMS tool to the vehicle's DLC with the OBD II

cable. Press the **POWER BUTTON** to turn on the tool.

- 2) Turn the ignition on but do not start the engine.
- 3) Make sure the testing mode is set to **All Wheels** mode in System Setting.
- 4) Follow the same process in **4.1 TPMS Sensor Check** to enter the activation screen. Use the **UP/DOWN** scroll button or **LEFT/RIGHT** scroll button to select the **TPMS Relearn** function. (Figure 4.20)




Figure 4.20

- 5) The tool will display a function screen as below. Use the **UP/DOWN** scroll button to select **TPMS Diagnosis** or **TPMS Sensor Information**, and press the **Y** button to continue. (Figure 4.21)





Figure 4.21

- 6) The **TPMS Diagnosis** function allows user to write IDs to vehicle, read IDs from vehicle, read/clear TPMS codes, read TPMS live data, perform active test and special functions.
- 7) The **TPMS Sensor Information** enables retrieval of the sensor make, OEM part no., and relearn information.

- *The **TPMS Diagnosis** function varies by vehicle being tested.*

 **NOTE:** *In this manner, the scan tool will communicate with the vehicle being tested. If there is a linking error, a notice screen will show up. Please refer to 3.9 Product Troubleshooting for more details.*

A. Write IDs to Vehicle

- 1) From the TPMS Diagnosis Menu, use the **UP/DOWN** scroll button to select the **Write IDs to Vehicle**, and press **Y** button. (Figure 4.22)




Figure 4.22

- 2) The tool will display the sensor IDs and positions for your confirmation. Select **“Yes”** to register ID in vehicle ECU, or **“No”** to exit.






Figure 4.23

- 3) Once the sensor IDs are successfully written, a confirm screen will show up. Press any key to continue the TPMS diagnostic procedure. (Figure 4.24)



Figure 4.24

-  **NOTE:** The sensor writing procedure may vary for different vehicles being serviced. Please follow the onscreen instruction and take appropriate measures and selections to complete the process.
-  **NOTE:** If there are untested sensors in the vehicle, the writing ID process cannot proceed. The tool will display a warning message as below.(Figure 4.25) In this case, follow the sensor check procedure to activate all sensors in vehicle and register sensor IDs again.




Figure 4.25

IMPORTANT: Make sure to turn the ignition off before connecting /disconnecting the OBDII Cable to/from the TPMS tool; otherwise it may cause the Malfunction Indicator Light (MIL) to turn on.

B. Read IDs from Vehicle

- 1) From the TPMS Diagnosis Menu, use the **UP/DOWN** scroll button to select the **Read IDs from Vehicle**, and press **Y** button. (Figure 4.22)
- 2) The tool will display the sensor IDs and positions for your viewing. Select “**Save**” to store data for future review, or “**Esc**” to exit without saving. (Figure 4.26).

Read IDs from Vehicle	
ID TYPE1 FL	8000E0
ID TYPE1 FR	002020
ID TYPE1 RR	00E000
ID TYPE1 RL	1E00E0
Esc	Save

Figure 4.26

C. Read Codes

- 1) From the TPMS Diagnosis Menu, use the **UP/DOWN** scroll button to select the **Read Codes**, and press **Y** button. (Figure 4.22)
- 2) The tool will display TPMS DTCs retrieved from the vehicle's ECU for your viewing. Select "**Save**" to store data for future review, or press "**N**" button to exit without saving. (Figure 4.27).




Figure 4.27

D. Erase Codes

- 1) From the TPMS Diagnosis Menu, use the **UP/DOWN** scroll button to select the **Erase Codes**, and press **Y** button. (Figure 4.22)
- 2) The tool will display a warning message for your confirmation. Select "**Yes**" to continue, "**No**" to exit. (Figure 4.28)




Figure 4.28

- 3) If the erase command is sent successfully, the screen will show as below (Figure 4.29). Press any button to continue. To make sure codes are erased clearly, run **Read Codes** again.




Figure 4.29

E. Live Data

In this function, you can not only read the live data but also record live data for later review.

- 1) From the TPMS Diagnosis Menu, use the **UP/DOWN** scroll button to select **Live Data**, and press **Y** button. (Figure 4.22)

All Data

- 1) From the Live Data menu, use the **UP/DOWN** scroll button to select **All Data** and press the **Y** button. (Figure 4.30)




Figure 4.30

- 2) The tool will display a list of all live sensor data. (Figure 4.31)

Live Data		
AIR PRESS FL	8.60	Kpa
AIR PRESS FR	10.32	Kpa
AIR PRESS RR	12.04	Kpa
AIR PRESS RL	13.76	Kpa
ID REGST FL1	Yet	
Save One Graphic Pause		

Figure 4.31

- Press the corresponding **FUNCTION BUTTON ‘Save’** to store the retrieved live data for later playback or printing. (Figure 4.31)
- Press the corresponding **FUNCTION BUTTON ‘Stop Save’** to stop saving data and resume live sensor data retrieving. (Figure 4.32)
- Press the corresponding **FUNCTION BUTTON ‘Pause’** to stop live sensor data retrieving.(Figure 4.31)
- Press the corresponding **FUNCTION BUTTON ‘Continue’** to resume live sensor data retrieving. (Figure 4.35)

Save 24 Items		
AIR PRESS FL	8.60	Kpa
AIR PRESS FR	10.32	Kpa
AIR PRESS RR	12.04	Kpa
AIR PRESS RL	13.76	Kpa
ID REGST FL1	Yet	
Stop Save One Graphic Pause		

Figure 4.32

- If the **‘One Graphic’** option is highlighted when a specific item is selected, the graphic information is available. (Figure 4.32)

- When the sensor data is shown in graph, the tool offers two more options: **Two Graphic** and **Merge Graphic**. The first option can display two graphs on the same screen (Figure 4.33), and the last option can merge the two graphs into one. (Figure 4.34).




Figure 4.33




Figure 4.34

- Press the corresponding **FUNCTION BUTTON 'Text'** or the **N** button to return to previous screen. (Figure 4.35)

Live Data		
AIR PRESS FL	8.60	Kpa
AIR PRESS FR	10.32	Kpa
AIR PRESS RR	12.04	Kpa
AIR PRESS RL	13.76	Kpa
ID REGST FL1	Yet	
<div>Save One Graphic Continue</div>		

Figure 4.35

Custom List

- 1) To retrieve customized live sensor data, use the **UP/DOWN** scroll button to select **Custom List** from **Live Data** and press the **Y** button. (Figure 4.30)
- 2) Use the **UP/DOWN** scroll button to move to the desired item and press the corresponding **FUNCTION BUTTON** 'Select' to choose. (Figure 4.36)

Custom List		
<input checked="" type="checkbox"/>	AIR PRESS FL	1
<input checked="" type="checkbox"/>	AIR PRESS FR	2
<input checked="" type="checkbox"/>	AIR PRESS RR	3
<input type="checkbox"/>	AIR PRESS RL	
<input type="checkbox"/>	ID REGST FL1	
<input type="checkbox"/>	ID REGST FR1	
<input type="checkbox"/>	ID REGST RR1	
<div>Clear All Select Select All</div>		

Figure 4.36


- The Selected items are marked with ticks on the left.
 - The number on the right indicates sequence of the selected item.
 - Press the corresponding **FUNCTION BUTTON** 'Clear' to unselect items, or press the corresponding **FUNCTION BUTTON** 'Select All'/'Clear All' to select or unselect all items. (Figure 4.36)
- 3) Press the **Y** button to confirm your selection and retrieve the

selected live sensor data.

- 4) Press the **N** button to return to the previous menu.

F. Active Test

- 1) From the TPMS Diagnosis Menu, use the **UP/DOWN** scroll button to select **Active Test**, and press **Y** button. (Figure 4.22)
- 2) The tool will display a list of available active tests for the vehicle being tested. (Figure 4.37).




Active Test	
1	FLAT TIRE WARNING
2	ID REGIST WARNING
3	WARNING LAMP
4	RUN FLAT/T WARN BUZZER
5	FLASHER
6	HORN

Figure 4.37

Taking **Flat Tire Warning** for example:

- 3) From **Active Test** Menu, use the **UP/DOWN** scroll button to select **Flat Tire Warning** function. (Figure 4.37)
- 4) Press the corresponding **FUNCTION BUTTON** ‘**ON**’ or ‘**OFF**’ to check whether the TPMS warning lamp on the vehicle is turning on or off. (Figure 4.38)




Active Test	
FLAT TIRE WARNING	OFF
ON	OFF

Figure 4.38

- 5) Press the **N** button to return to the previous menu.

G. Special Function

- 1) From the TPMS Diagnosis Menu, use the **UP/DOWN** scroll button to select **Special Function**, and press **Y** button. (Figure 4.22)
- 2) The tool will display a list of available special functions for the vehicle being tested. (Figure 4.39).

 **NOTE:** *The Special Function menu may vary for different vehicles being serviced. Please follow the onscreen instruction and take appropriate measures and selections to complete the process.*

Taking **Switch TPMS between On/Off** for example:

- 3) To manually switch on/off TPM system, use the **UP/DOWN** scroll button to select **Switch TPMS between On/Off** and press the **Y** button. (Figure 4.39)




Figure 4.39

- 4) The tool displays a message for your confirmation. Select **OK** to continue and **Cancel** to exit.




Figure 4.40

- 5) Press the corresponding **FUNCTION BUTTON 'ON' or 'OFF'** to turn ON/OFF the TPMS on the vehicle. (Figure 4.41)




Figure 4.41

- 6) Press the corresponding **FUNCTION BUTTON 'Back'** to return to previous screen.

H. ECU Part Number

- 1) To retrieve ECU part number, use the **UP/DOWN** scroll button to select **ECU Part Number** function item from the TPMS Diagnosis Menu. (Figure 4.22)
- 2) The ECU part number will be displayed once it's successfully retrieved. Press the corresponding **FUNCTION BUTTON 'Save'** to store for later playback and printing. (Figure 4.42)

Ecu Information	
ECU Part number	284B2-EH10Q
Esc	Save

Figure 4.42

- 3) Press the corresponding **FUNCTION BUTTON** 'Esc' to return to previous menu.

4.3 Audit Report

After the user finished the TPMS test, the tool is capable of presenting all of its stored TPMS data in a HTML file when connected to a PC via an USB cable.

The tool will automatically pop up a explorer window in PC screen when connected to an active USB port on the PC. Make sure the tool is powered on. Otherwise, there will be no communication between the tool and computer.

Once the explorer window is open, you may view a file by double-clicking on the file. If this explorer window does not automatically pop up, the user may browse for the newly connected device manually.

The data presented is in a HTML form format that displays not only information regarding the TPMS, but also automatically updates with the date. It also provides data entry areas for other tester and vehicle data.

MaxiTPMS TS601

Vehicle Make Tested: Honda Odyssey Touring 2005-2007

Test Performed by:

Owners Name:

License Plate No:

Model and Year:

Comments:

Wheel	BCM ID Hex	BCM ID Dec	ID Hex	ID Dec	Pressure	Temperature	Battery State	Modulation	OEM Part #:
FL	8D857ACF	2374335183	B8220764	30892378600	240kpa	25	OK	315AM	06421-83V-A04
FR	Untested	Untested	Untested	Untested	Untested	Untested	Untested	Untested	Untested
RR	Untested	Untested	Untested	Untested	Untested	Untested	Untested	Untested	Untested
RL	Untested	Untested	Untested	Untested	Untested	Untested	Untested	Untested	Untested
SP	Untested	Untested	Untested	Untested	Untested	Untested	Untested	Untested	Untested

Figure 4.43

5. RKE & RF Monitor

Today's keyless remotes -- also known as key fobs -- make life easier. But when your key fob stops working or starts to perform sporadically, it will be particularly frustrating. Check your key fob to make sure it is in top condition so it will work when you really need it.

Since a key fob is attuned to a special frequency that is only detected by the car for which it was issued, you will need to use your vehicle to test the fob. Otherwise you will have to take it to a dealership or an automotive locksmith to have it tested for the right frequency. But with our TPMS tool, the key fob testing becomes easy and convenient.

- 1) Use the **UP/DOWN** scroll button and **LEFT/RIGHT** scroll button to select **RKE & RF** from **Main Menu** (Figure 3.1), and press the **Y** button to confirm.
- 2) Hold the key fob very close to the tool and press the function buttons on key fob to test. If the button works and the key fob is sending a signal, the tool will beep and the screen shows as below. If the button does not work, the tool will do nothing. To make sure each button is working properly, please test each button in turn.




Figure 5.1

- The progress bar indicates the approximate power level of

the key fob.

- The stronger the signal, the higher the beep tone.
- The tool only tests 315MHz and 433MHz key fobs.

3) Press the **N** button to return to previous menu.


6. OBDII Diagnostics

The OBD II Diagnostics function is a fast-access option that allows you to carry out a quick test on the engine system of OBD II-compliant vehicles.

When more than one vehicle control module is detected by the scan tool, you will be prompted to select the module where the data may be retrieved. The most often to be selected are the Power-train Control Module [PCM] and Transmission Control Module [TCM].

CAUTION: Don't connect or disconnect any test equipment with ignition on or engine running.

- 1) Turn the ignition off.
- 2) Locate the vehicle's 16-pin Data Link Connector (DLC).
- 3) Plug the scan tool cable connector into the vehicle's DLC.
- 4) Turn the ignition on. Engine can be off or running.
- 5) Turn on the scan tool. Select **OBD II** from the **Main Screen**. (Figure 3.1)
- 6) Press the **Y** button to wait for the Menu to appear. A sequence of messages displaying the OBD II protocols will be observed on the display until the vehicle protocol is detected.

 *If the scan tool fails to communicate with the vehicle's ECU (Engine Control Unit) more than three times, a "LINKING ERROR!" message shows up on the display.*

- ✓ Verify that the ignition is ON.
- ✓ Check if the scan tool's OBD II connector is securely connected to the vehicle's DLC.
- ✓ Verify that the vehicle is OBD II compliant.
- ✓ Turn the ignition off and wait for about 10 seconds. Turn the ignition back to on and repeat the procedure from step 5.

● *If the "LINKING ERROR" message does not go away, then there might be problems for the scan tool to communicate with*

the vehicle. Contact your local distributor or the manufacturer's customer service department for assistance.

- 7) View a summary of system status (MIL status, DTC counts, Monitor status) on screen. (Figure 6.1)

System Status	
MIL Status	ON
Codes Found	127
Monitors N/A	0
Monitors OK	0
Monitors INC	10
OK	Save

Figure 6.1

- If more than one module is detected, you will be prompted to select a module before testing. (Figure 6.2)

Control Module	
1	Module \$10
2	Module \$18
3	Module \$28
4	Module \$98

Figure 6.2

- Use the **UP/DOWN** scroll button to select a module and press the **Y** button.

6.1 Read Codes

- 1) From **Diagnostic Menu**, use the **UP/DOWN** scroll button to select **Read Codes** and press the **Y** button. (Figure 6.3)

Diagnostic Menu	
1	System Status
2	Read Codes
3	Erase Codes
4	Live Data
5	Freeze Frame
6	I/M Readiness
7	O2 Monitor Test

Figure 6.3

- 2) Use the **UP/DOWN** scroll button to select **Stored Codes**, **Pending Codes** or **Permanent Codes** from the **Read Codes** menu and press the **Y** button. (Figure 6.4)

Read Codes	
1	Stored Codes
2	Pending Codes
3	Permanent Codes

Figure 6.4

- 3) A screen of trouble codes will appear. If more than one DTC is found, use the **UP/DOWN** scroll button to check all the codes. (Figure 6.5)

Trouble Codes	
P0001	\$07E8
Fuel Volume Regulator Control Circuit/Open	
P0002	\$07E8
Fuel Volume Regulator Control Circuit Range/Performance	
P0003	\$07E8
Save	

Figure 6.5

6.2 Erase Codes

- *This function is performed with key on engine off (KOEO). Do not start the engine.*
- 1) Use the **UP/DOWN** scroll buttons to select **Erase Codes** from **Diagnostics Menu** and press the **Y** button. (Figure 6.3)
- 2) A confirm screen will show up. Press the corresponding **FUNCTION BUTTON** ‘Yes’ to continue; otherwise press the corresponding **FUNCTION BUTTON** ‘NO’ to exit. (Figure 6.6)




Figure 6.6

- 3) If the codes are cleared successfully, an “**Erase Done!**” message shows on the screen. Press any key to continue. (Figure 6.7)




Figure 6.7

6.3 Live Data

In this function, you can not only read the live data but also retrieve data for later review.

- 1) To view live data, use the **UP/DOWN** scroll button to select **Live Data** from **Diagnostic Menu** and press the **Y** button. (Figure 6.3)
- 2) Wait a few seconds while the scan tool validates the PID MAP. (Figure 6.8)




Figure 6.8

Complete List

- 1) To view complete set of data, use the **UP/DOWN** scroll button to select **Complete List** from **Live Data** menu and press the **Y** button. (Figure 6.9)




Figure 6.9

- 2) Use the **UP/DOWN** scroll button to select a specific item or use

the **LEFT/RIGHT** scroll button to turn to next page. (Figure 6.10)

Complete List		
Calculated Load Value	100.0	%
Absolute Throttle Position	100.0	%
Commanded Secondary Air Status	UPS	
<div>Save One Graphic Pause</div>		

Figure 6.10

Custom List

- 1) To view customized PID data, use the **UP/DOWN** scroll button to select **Custom List** from **Live Data** menu and press the **Y** button. (Figure 6.9)
- 2) Use the **UP/DOWN** scroll button to move to the desired item and press the corresponding **FUNCTION BUTTON 'Select'** to choose. (Figure 6.11)

Custom List		
<input type="checkbox"/>	Numbers of DTCs	
<input type="checkbox"/>	DTC that caused required freeze frame data storage	
<input type="checkbox"/>	Fuel system 1 status	
<input type="checkbox"/>	Fuel system 2 status	
<input type="checkbox"/>	Calculated Load Value	
<input type="checkbox"/>	Absolute Throttle Position	
<div>Clear All Select Select All</div>		

Figure 6.11

- 3) Press the corresponding **FUNCTION BUTTON 'Clear'** to unselect items, or press the corresponding **FUNCTION BUTTON 'Select All'/'Clear All'** to select or unselect all items.

- 4) Press the **Y** button to view selected PIDs on screen. (Figure 6.12)

Custom List		
Commanded Secondary	UPS	
Air Status		
Absolute Throttle	100.0	%
Position		
Numbers of DTCs	127	
<div>Save One Graphic Pause</div>		

Figure 6.12

- 5) Press the **N** button to return to previous menu.

6.4 Freeze Frame

- 1) To view freeze frame data, use the **UP/DOWN** scroll button to select **Freeze Frame** from **Diagnostic Menu** and press the **Y** button. (Figure 6.3)
- 2) Wait a few seconds while the scan tool validates the PID MAP.
- 3) Use the **UP/DOWN** scroll button to select a specific item or use the **LEFT/RIGHT** scroll button to turn to next page. (Figure 6.13)

Freeze Frame		
Engine Coolant	419	°F
Temperature		
Short Term Fuel Trim	99.2	%
-Bank 1		
Short Term Fuel Trim	99.2	%
-Bank 3		
Long Term Fuel Trim -	99.2	%
Save		

Figure 6.13

- 4) If there is no available freeze frame data, an advisory message **“No freeze frame data stored!”** shows on the display.

- 5) Press the corresponding **FUNCTION BUTTON** 'Save' to record freeze frame to **Review Data** for later playback or printing. A confirming message "**Save success!**" shows on the screen and press any key to continue.

6.5 Retrieving I/M Readiness Status

Some latest vehicle models may support two types of **I/M Readiness** tests:

- A. *Since DTCs Cleared* - indicates status of the monitors since the DTCs are erased.
- B. *This Drive Cycle* - indicates status of monitors since the beginning of the current drive cycle.

An I/M Readiness Status result of "NO" does not necessarily indicate that the vehicle being tested will fail the state I/M inspection. For some states, one or more such monitors may be allowed to be "Not Ready" to pass the emissions inspection.

- **"OK"** -- Indicates that a particular monitor being checked has completed its diagnostic testing.
 - **"INC"** -- Indicates that a particular monitor being checked has not completed its diagnostic testing.
 - **"N/A"** -- The monitor is not supported on that vehicle.
- 1) Use the **UP/DOWN** scroll button to select **I/M Readiness** from **Diagnostic Menu** and press the **Y** button. (Figure 6.3)
 - 2) Wait a few seconds while the scan tool validates the PID MAP.
 - 3) If the vehicle supports both types of tests, then both types will be shown on the screen for selection. (Figure 6.14)

I/M Readiness	
1	Since DTCs cleared
2	This driving cycle

Figure 6.14

- 4) Use the **UP/DOWN** scroll button, as necessary, to view the status of the MIL light (“**ON**” or “**OFF**”) and the monitors.

Since DTCs cleared		
Malfunction Indicator	ON	
Lamp(ML) Status		
Misfire Monitoring	INC	
Fuel system Monitoring	INC	
Comprehensive component	INC	
N		

Figure 6.15

- 5) If the vehicle supports readiness test of “**This Drive Cycle**”, a screen of the following displays: (Figure 6.16)

This driving cycle		
Misfire Monitoring	INC	
Fuel system Monitoring	INC	
Comprehensive component	INC	
Monitoring		
Catalyst Monitoring	INC	
N		

Figure 6.16

- 6) Use the **UP/DOWN** scroll button for more PIDs if additional information is available for more than one page. Or use the **LEFT/RIGHT** scroll button to view PIDs in the previous/next page.
- 7) Press the **N** button to return to **previous menu**.

6.6 O2 Monitor Test

- 1) Use the **UP/DOWN** scroll button to select **O2 Monitor Test** from **Diagnostic Menu** and press the **Y** button. (Figure 6.3)
- 2) Wait a few seconds while the scan tool validates the PID MAP.
- 3) Use the **UP/DOWN** scroll button to select O2 sensor from **O2 Monitor Test** menu and press the **Y** button. (Figure 6.17)




Figure 6.17

- If the vehicle does not support the mode, an advisory message will be displayed on the screen. (Figure 6.18)




Figure 6.18

- 4) Select a specific item and press the **Y** button to view test value, maximum value, minimum value, and determine if it is OK. (Figure 6.19)

O2 Bank1 Sensor1		
1	Rich-Lean Threshd(V)	
2	Lean-Rich Threshd(V)	
3	Low for Switch(V)	
4	High for Switch(V)	
5	Rich-Lean Threshd(s)	
6	Lean-Rich Threshd(s)	
7	Min for test Cys(V)	

Figure 6.19

- 5) Press the corresponding **FUNCTION BUTTON** 'Save' to store to Review Data for later playback and print or press the **N** button to return to previous menu. (Figure 6.20)

Rich-Lean Threshd(V)		
Module	\$10	
Test Value	0.005	
Min Limit	0.435	
Max Limit	0.010	
Save		

Figure 6.20

6.7 On-Board Monitor Test

- 1) Use the **UP/DOWN** scroll button to select **On-Board Monitor Test** from **Diagnostic Menu** and press the **Y** button. (Figure 6.3)
- 2) Wait a few seconds while the scan tool validates the PID MAP.
- 3) Select the vehicle make and press the **Y** button. (If you have selected the vehicle before, the **Vehicle Manufacturer** screen would not appear again)

Vehicle Manufacturer	
1	BUICK
2	BMW
3	CADILLAC
4	CHEVROLET
5	CHRYSLER
6	FORD
7	GM

Figure 6.21

- 4) A list of specific monitoring systems appears. Select one of the items and press the **Y** button. (Figure 6.22)

On-Board Monitor Test(Vehicle M	
1	Test \$01 Data
2	Secondary Air Injection Reaction System Monitor
3	O2 Sensor Heater System Time to Activity Monitor
4	Exhaust Gas Recirculation System Monitor

Figure 6.22

- 5) A screen of test results shows up. (Figure 6.23)

Test \$01 Data		
ID	\$00	
Module	\$10	
Test Limit	0021	
Min Limit	2223	
Max Limit	
N		

Figure 6.23

- 6) Press the **N** button to return to previous menus.

6.8 Component Test

- 1) Use the **UP/DOWN** scroll button to select **Component Test** from **Diagnostic Menu** and press the **Y** button. (Figure 6.3)
- 2) Wait for the scan tool to display the **Component Test** menu. (Figure 6.24)




Figure 6.24

- 3) If the test has been initiated by the vehicle, a confirmation message will be displayed on the screen. (Figure 6.25)




Figure 6.25

- If the test has not been successfully initiated by the vehicle, a message “**LINKING ERROR**” shows up. Make sure the tool and DLC are connected securely.
- Some vehicles do not allow scan tools to control vehicle systems or components. If the vehicle under test does not

support the EVAP Leak Test, an advisory message is displayed on the screen. (Figure 6.26)




Figure 6.26

- 4) Wait a few seconds or press any key to return to previous screen.

6.9 Viewing Vehicle Information

This function enables retrieval of Vehicle ID No. (VIN), Calibration ID Nos. (CINs), Calibration Verification Nos.(CVNs), In-use Performance Tracking, and ECU Name.

- 1) From the **Diagnostic Menu**, use the **UP/DOWN** scroll button to select **Vehicle Info.** and press the **Y** button. (Figure 6.3)
- 2) Wait for the scan tool to display the **Vehicle Info.** menu. (Figure 6.27)




Figure 6.27

- If the vehicle does not support this mode, a message shows on the display warning that the mode is not supported.

- 3) From **Vehicle Info.** menu, use the **UP/DOWN** scroll button to select **Vehicle ID Number** and press the **Y** button.

Vehicle ID Number	
VIN	LVSFCFAE16F01 5498
N	Save

Figure 6.28

- 4) Follow the same procedures to retrieve **Calibration ID**, **Calibration Verification No.**, **In-use Performance Tracking** and **ECU Name**.

6.10 Modules Present

- 1) Use the **UP/DOWN** scroll button to select **Modules Present** from **Diagnostic Menu** and press the **Y** button. (Figure 6.3)
- 2) View modules present with their IDs and communication protocols. (Figure 6.29)

Modules Present		
Protocol	ID	
CAN STD SLOW	\$07E8	
Save		

Figure 6.29

- 3) Press the corresponding **FUNCTION BUTTON** '**Save**' to store the modules data to **Review Data**, or press the **N** button to exit.

7. Review Data

The Review Data function allows user to view and print out saved data of the latest TPMS diagnostic recordings and all diagnostic data retrieved from the ECUs of the OBD II-compliant vehicles by the service tool.

Use the **UP/DOWN** and **LEFT/RIGHT** scroll button to select **Review Data** from Main Screen (Figure 3.1), and wait for the review data menu to appear.(Figure 7.1)

- 1) Use the **UP/DOWN** scroll button to select **TPMS** or **OBDII** from **Review Data** and press the **Y** button. (Figure 7.1)




Figure 7.1

- 2) Use the **UP/DOWN** scroll button to select the desired stored data (taking **Read IDs from Vehicle** as an example) from **TPMS** menu and press the **Y** button.





Figure 7.2

- 3) A list of retrieved sensor IDs will show on the screen.

Read IDs from Vehicle	
ID TYPE1 FL	8000E0
ID TYPE1 FR	002020
ID TYPE1 RR	00E000
ID TYPE1 RL	1E00E0
Print	

Figure 7.3

- ✧ Print --- Select this function to print out the data on screen. For detailed instructions, refer to **8.1 print data**.
- ✧ Delete --- Use the **RIGHT** scroll button to delete the selected data.
- ✧ Delete All --- Use the **LEFT** scroll button to delete all data on the screen.

 **NOTE: Don't use Delete All unless you are definitely sure what you are going to proceed.**

8. Print and Update

To print out retrieved data or update software, you will need the followings:

- ✓ TS601 tool with SD card inserted
- ✓ PC or laptop with USB ports
- ✓ USB cable

8.1 Print Data

The **Print Data** function allows printing out data retrieved by the service tool by connecting the scan tool to a PC or laptop with the USB cable supplied.

- 1) Install the **PC Suit** program to the PC from the supplied CD.
- 2) Connect the scanner to computer with the USB cable supplied.
- 3) Run **Printer** software on computer.
- 4) Select **Review Data** function in **Main Screen** of the TPMS tool. In data menu screen, use the **UP/DOWN** scroll button to select the data you want to print. Wait for the reviewing window to display (Figure 7.3), and then press the corresponding **FUNCTION BUTTON 'Print'** and the selected file will be uploaded to your computer.
- 5) The **Printer** will show as below.




Figure 8.1

- 6) The selected data will display on the textbox of **Printer**. By selecting the function keys on the right, you could execute the following operations:

Print – Print all data in the textbox to a printer connected to your computer.

Edit – Once clicked, the software will automatically open a NOTEPAD window with all recorded data showing on.

Copy – Copy all data in the textbox to the clipboard.

Clear – Delete all data in the textbox.

Exit – Quit the operation.


- 7) You are also allowed to edit, copy, and delete the data in the **Printer** window.

8.2 Software update

This function allows you to update the scan tool software through a computer.

◆ Register the Tool

User could update the scan tool **ONLY** after you had registered the tool on our website: www.maxidas.com. Then you could download software, update online, retrieve information and get warranty service.

 **NOTE:** *Prior to registration, please confirm your network is working properly.*

1. Visit our website www.maxidas.com.
2. Click on the **Update** tool bar at the top of the screen, and then select **User Register**, or click on the **Updates** column in the lower right corner of the screen, and select **Register**.
3. The screen of Register Information appears. Please read through the instructions, and click on **Agree** to continue.

- Put in the Product Serial No. and Register Password, and click on **Next**. (Figure 8.2)
- Follow the instructions on screen to finish the registration.



Figure 8.2

NOTE: Please use the **About** function to find out the **Product Serial No. and Register Password**. For details, please refer to the **Section 3.8 System Setting**.

◆ Update Procedure

Autel frequently releases software updates that you can download. The Update feature makes it very easy to determine and get exactly what you need.

Users could either choose to update the TPMS tool via USB connection or SD card.

✓ Update via USB

Connect the tool with computer with USB cable. Then switch on the tool.

✓ Update via SD card

Remove the SD card from the tool and connect it with computer.

Follow the update procedure to finish updating.

- Run Update Client in the **PC Suit** program. Wait for the Log In

window to pop up. (Figure 8.3)



Figure 8.3

- 2) Put in the user name and password and wait for the Update window to display. If you forget your password unintentionally, you may always click the [**Forget your password?**] to link to our website and get your password back.
- 3) In the Update window, select the items you want to install. Usually, you should install all available updates.




Figure 8.4

Generally there are two ways to update programs:

Batch updating

- 1) Select the programs that you would update by clicking on the check boxes next to those items. Then click the **Update**

Selected Items button on the right side of screen.

- 2) Or click on the Select All checkbox on the right side of screen and all updatable items will be selected automatically. Then click the **Update Selected Items** button on the right side of screen.
- 3) Check the updating process by observing the upper left progress bar [downloading] and upper right progress bar [installing]. You may also find progress information in the Status column of updated items.
- 4) When the downloading is completed, the downloaded programs will be installed automatically. The new version will replace the old version.
- 5) Anytime you could click the **Pause** button on the right side of screen to suspend all progresses, and the state of those suspended items would change to STOPPED.
- 6) To resume updating process, you may need to select those suspended items again, and then click the **Update Selected Items** button. The progress will resume from the break point.

Single updating

- 1) Find out the desired updating item and click the **INSTALL** button in the same line, and the **INSTALL** button changes to **STOP** at the same time.
- 2) Check the updating process by observing the upper left progress bar [downloading] and upper right progress bar [installing]. You may also find progress information in the Status column of updated items.
- 3) Anytime you could click the Pause button in the line to suspend this progress, and the state of this item would change to STOPPED.
- 4) To resume updating process, click the **INSTALL** button in the line again. The progress will resume from the break point.

- 5) When the downloading is completed, the downloaded program will be installed automatically. The new version will replace the old one.
- 6) Once the update is complete, disconnect the tool from the computer. It is now updated and ready to go.
- 7) For users who choose to update by SD card, please insert the SD card into the scan tool, and switch on the TPMS tool. It's now updated and ready to go.

◆ View or Delete Programs

To view the list of installed programs or to delete an installed program, please follow these steps:

- 1) Click on the Installed Programs tag entry and the page will show the list of programs installed.
- 2) Select the program(s) that you would delete.

✧ **Batch delete:** Select the programs that you would delete by clicking on the check boxes to the left of those items. Then click the **DELETE** button on the right side of screen.

✧ **Single delete:** Click the **UNINSTALL** button in the line of your would-be-deleted program.

- 3) A window asking “**Are you sure to delete the software?**” will pop up for your confirmation.




Figure 8.5

- Click on **Yes** to delete the program(s) selected, or on **No** to cancel the action.
- The deleted program will automatically add to the end of program list in the UPDATE page in case you would like to install again.

Theoretically, all programs of the latest versions will be automatically compatible with the older versions, but if your TPMS tool does have a compatibility problem and need to retrieve the older version for some programs, please delete the new versions first then install the older version again. Choose the older version from the pull-down menu of program version.




Figure 8.6

9. Compliance Information

FCC COMPLIANCE

FCC ID:WQ83017501601

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: **i.** Reorient or relocate the receiving antenna. **ii.** Increase the separation between the equipment and receiver. **iii.** Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. **iv.** Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The term "IC" before the radio certification number only signifies that IC technical specifications were met.

RoHS COMPLIANCE

This device is declared to be in compliance with the European RoHS Directive 2011/65/EU.

CE COMPLIANCE

This product is declared to conform to the essential requirements of the following Directives and carries the CE mark accordingly: EMC Directive 2004/108/EC
R&TTE Directive 1999/5/EC Low Voltage Directive 2006/95/EC

10. Warranty and Service

10.1 Limited One Year Warranty

Autel warrants to its customers that this product will be free from all defects in materials and workmanship for a period of one (1) year from the date of the original purchase, subject to the following terms and conditions:

- 1) The sole responsibility of Autel under the Warranty is limited to either the repair or, at the option of Autel, replacement of the TPMS tool at no charge with Proof of Purchase. The sales receipt may be used for this purpose.
- 2) This warranty does not apply to damage due directly or indirectly, to misuse, abuse, negligence or accidents, repairs or alterations outside our Service Center or facilities, criminal activity, improper installation, normal wear and tear, or to lack of maintenance.
- 3) Autel shall not be liable for any incidental or consequential damages arising from the use, misuse, or mounting of the TPMS tool. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- 4) All information in this manual is based on the latest information available at the time of publication and no warranty can be made for its accuracy or completeness. Autel reserves the right to make changes at any time without notice.

10.2 Service Procedures

If you have any questions, please contact your local store, distributor or visit our website at www.auteltech.com.

If it becomes necessary to return the tool for repair, contact your local distributor for more information.